


What's in the box:

RGB Control Box
 2 - 1/4" Screws
 1 - Module Connector Cable
 1 - RGB Remote Control



- 1** Use the supplied screws to attach the Panorama Module to the top of your canopy as shown in **Figure 1**. Be sure the bracket is installed with the rubber stand-off to allow a gap between the heat sink and surface of your canopy.
- 2** Locate the 24-watt wall transformer and connect the male DC plug to the female DC receptacle on the RGB Control Box shown in **Figure 1**.
- 3** Finally, connect the output of the black connector from the module to the black connector included in the RGB control kit. Connect white connector end with white connector on control box, arrows facing up. Mount control box in a dry location using included screws. Ensure receiver tip (black tip) is in a location to receive signals from the remote. Remove clear tape from remote battery compartment. Plug power supply into a Ground to FaultCircuit Interrupter (GFCI) and AC outlet. Follow keypad instructions included for RGB settings.

