

Panorama Pro LED Tank Mount System Model#5011 & 5012

What's in the box:

- 1- Tank Mount Hinged Assembly (Pre-assembled)
- 2 - "L" Aluminum Arms
- 2 - Screws with washers & bolts


Please note: This system is only designed for the Panorama PRO LED Fixture. DO NOT USE on the first generation Panorama LED fixture.



Assembly Instructions For Rimless / Frameless Aquariums

1 Unpack Tank Mount Assembly and ensure all components listed above are included. If your aquarium is a rimless (frameless) aquarium, please proceed to Step 2. If your tank has a plastic frame around it, please follow the instructions on the reverse side.

2 Slide "L" support arms onto bracket as shown below. Using a phillips head screwdriver, attach L brackets to arm and tighten.




3 Loosen nylon bolts located on the hinge. Clean glass where assembly will be installed, ensure it is free of any wires, algae or debris. Position tank mount assembly to the aquarium and attach to glass by hand tightening the nylon bolts.

4 Slide Panorama Pro Fixture onto rails, ensuring light cables do not get wet. We suggest locating the cord above the tank mount to ensure it does not get crimped under the hinge assembly. To balance fixture, lift open and turn the vertical nylon bolts counter clockwise to lift, clockwise to lower. The fixture can now be connected per the instructions.

5 To lift fixture open, gently slide fixture back and lift completely to 90 degrees. Please note: the fixture must be lifted a complete 90 degrees (vertical) for the hinge to keep it in place. CAUTION: When lowering fixture, please ensure it is done slowly. Ensure your fingers do not get caught under hinge when closing. Ensure power cable does not get crimped when closing.

6 Over time, it may become necessary to tighten the hinge. To do so, simply use a phillips screwdriver and tighten hinge by turning it clockwise (hand tighten only.) For maintenance, please ensure screw holes are kept free of algae and debris.



Please note: This system is only designed for the Panorama PRO LED Fixture. DO NOT USE on the first generation Panorama LED fixture.

Assembly Instructions For Framed Aquariums


*** Fits framed aquariums with up to a 1" thick frame**

1 Unpack Tank Mount Assembly and ensure all components listed on reverse page are included. If your tank has no frame around (rimless/frameless), please follow the instructions on the reverse side.


2 Remove nylon bolts from tank mount. Using a socket wrench, remove the two silver hinge nuts which attach the adjustable hinge to the plastic tank mount.

Remove hinge nuts using socket wrench


Remove nylon bolts




3 Slide the 2 bolts completely out of the tank mount. Components should all be dis-assembled as shown.



4 Slide the 2 bolts completely out of the tank mount. Reinsert bolts through the opposite side. Re-attach hinge washers and nuts using the socket wrench and tighten.



Re-attach hinge washers and nuts, tighten with socket wrench.



5 Re-insert two nylon bolts in lower (bottom outside) two holes on the bracket. Position tank mount assembly on aquarium and hand-tighten nylon bolts to attach. The nylon bolts should be located inside the aquarium. Reverse this instruction sheet and follow steps 2 through 6 for final installation.

Insert nylon bolts into bottom holes of tank mount and hand tighten.

